

TEMPORARY ROOF PROTECTION

HOUSEWRAP SEAMING TAPE

HOUSEWRAP

SYNTHETIC ROOF UNDERLAYMENT

WE
HAVE
YOU
COVERED

REX™ Wrap Plus



REX™ WRAP PLUS INSTALLATION

1. Begin by aligning the bottom edge of the roll with the base of the wall, approximately 6" (152 mm) from a corner, folding several inches of the material under itself and fasten securely to a framing member. Be sure that the installation is horizontal on the vertical wall.
2. Unroll REX™ Wrap Plus with the printed side out, wrapping the entire building including door and window openings. Plastic cap nails or staples with a minimum 1" (25 mm) crown may be used. Fasteners shall be spaced a maximum of 16" (406 mm) on center along studs and 8" (203 mm) on center along top and bottom sill plates. When installing REX™ Wrap Plus over non-structural sheathing products or foam insulation boards, fasteners must penetrate the framing members no less than 1/2" (13 mm) and spaced as noted above.
3. Cut through REX™ Wrap Plus using a modified "I" pattern at door and window openings. Fold excess material inside the rough openings and fasten securely through the layers to a framing member.
4. If door frames and windows are already installed, trim REX™ Wrap Plus as close as possible and tape using contractor tape to seal seams around openings.
5. For vertical laps, fold the edge of REX™ Wrap Plus under and attach to the structural sheathing or framing member. The seams must be overlapped a minimum of 6" (152 mm) unless otherwise specified.
6. A minimum 2" (51 mm) overlap should be used for all horizontal laps.
7. All vertical and horizontal laps should be taped using contractor tape. Final wall covering should be installed within 6 months of the installation of REX™ Wrap Plus.



Alpha ProTech Engineered Products, Inc.

301 South Blanchard St.
Valdosta, GA 31601
866-312-1837

Manufacturing & Distribution Facilities

Valdosta, Georgia
Nogales, Arizona
Salt Lake City, Utah

AlphaProTech